

Paw Brothers® Professional Modular Cages

Cage Connection Instructions



Required Item Number: PBP89478 Modular Cage Connector Set/20

Tools Needed: #2 Phillips Screwdriver.

Warning! Do not stack the cages without installing cage connectors.

Step 1 Connect the cages using the connectors shown above. Remove the sheet metal screws at the connection points desired. Install the connectors using the same sheet metal screws. Do not over tighten the screws.

Step 2. After installing all connectors, test the entire bank for stability. The entire assembly may need to settle for 24 hours before all doors close properly.

Note: Due to the limitless configurations you may have extra cage connectors.

